





How to Insert a .PKT File

1. Within Civil 3D, browse to the Tool Palettes, and right-click on the top or side bar to select Import Subassemblies.



2. Select the source file(s) and then the Tool Palette destination



3. Files are created and stored at C:
ProgramData\Autodesk\C3D
20xx\enu\Imported Tools